



- We recommend using a **1-1/2" [39mm]** hole saw for the main outlet, and **1-1/8" [29mm]** hole saw for the vacuum breaker portion.
  - Drilling smaller holes first is generally easiest.
    - Both holes can be 1-1/2" if needed.
  - Remove enough material in between holes to clear vacuum breaker.
- The entry hole shape does not need to be exact, just within the four mounting points.
  - A template is provided inside each hydrant box.